

10744

Make and Model	Year	Mount Style
Chev/GMC Long Box Extended Cab	2011-2012	Front Split Frame



Tools required

3/4" Wrench, 3/4" Socket, Ratchet or Impact Gun

INSTRUCTIONS:

- 1) Locate placement of tie-down on vehicle's frame between cab and box. **FIG 1A**
- 2) Locate 5/8" hole on frame and bolt tie-down to frame with hardware provided. **FIG 1B**
- 3) Next, remove body bolt above tie-down. **FIG 1B & 1C**
- 4) Attach tie-down support arm to truck making sure 1/2" washer is between tie-down support arm and body bushing plate. **FIG 1D & 1E**
- 5) Bolt support arm to tie-down and torque all bolts. **FIG 1F**
- 6) Tighten up all remaining bolts and repeat steps for other side.

NOTE: WHEN DRILLING WATCH OUT FOR FUEL AND ELETRICAL LINES ON THE DRIVER SIDE FRAME

Note: Check and re-tighten all nuts and bolts after initial use.

WARNING: CAMPER NOT TO EXCEED CAPACITY OF VEHICLE